

**BRP-Powertrain**  
MAINTENANCE MANUAL

**2) Time limit**

**| General**

**NOTICE**

A general overhaul is due after a defined period of operation or after a specified calendar life since initial start of operation (whichever comes first).

The time limit for engine operation will be specified by the TBO.

---

**| After reaching this time limit**

**NOTICE**

After reaching this time limit, the engine has to be shipped to an authorized ROTAX overhaul facility.

For an overhaul, the engine must be removed from the aircraft, be cleaned, preserved and all openings to be closed to prevent entering of contaminants.

---

d02875.fm